



# 1020



no more costly unsown strips

air seeder  
blockage monitor



[www.farmscanag.com](http://www.farmscanag.com)





## NO MORE COSTLY UNSOWN STRIPS

Day or night there's no need to continually check the machine. The 1020 monitor warns you before major blockages end up costing you time and money!

The result is much less downtime, faster seeding and complete peace of mind.

Its patented Red Eye sensors are a proven performer with hundreds of systems in operation. It can pay for itself fast!

## HOW IT WORKS

Fully sealed impact sensors equipped with bright red lights (Red Eye) are bolted to each secondary distribution head.

Sensors are then interconnected on a simple partyline cable that runs across the implement, avoiding the need for messy separate wires to each sensor.

As material flows, the sensor listens to the sound level according to sowing rates of seed and fertiliser, all the operator adjusts is the sensitivity control until the cab warning light remains just off - simple as that.

A drop in flowrate or blockage at any secondary head will activate the Red Eye at the sensor causing the cab alarm and warning light to activate.

By switching to Hold, the operator can freeze the system and a quick inspection of all sensors will immediately pinpoint the problem.

The 1020 assists in picking many other problems with airseeder such as fan too slow or not engaged, disconnected and blocked primary hoses, lids not properly shut, empty bins, broken drives etc.

Optional Low Bin Sensors are available for connection on the party line system to give early warning on low bin levels.

## ORDER OPTIONS

- 1020 Airseeder Blockage Monitor Kit :** Monitors, mounting hardware, 8m power cable, 5m tractor cable, 40m sensor cable, 2 sets break away connectors, 6 secondary head sensors and junction box sets
- 1020T Airseeder Blockage Twin Shoot Monitor Kit**  
As above but doubled
- 1021 Secondary Head Sensor Kit :** 1x head sensor & 1x 3 way junction box with mounting bolts & washers
- 1022 Low Bin Sensor Kit :** Provides audible warning through monitor when bin is low. Includes 1x bin level sensor & 1x 3 way junction box
- A-1021 Replacement Head Sensor Only**
- A-1022A Replacement Bin Level Sensor Only**